ICON

Transmitter Configuration Kit with USB Communication

ICON is a complete kit for PC configuration of all transmitters in the INOR product line, except for the Meso transmitters, see page 25 and 33.
The kit contains the INOR USB Interface, transmitters cables and the new software, Consoft.
Communication with the connected transmitter is established automatically, without any problems to match the PC communication port to the software.

- USB communication
- Automatic matching of communication ports
- Automatic transmitter identification for quick start up
- Diagnostic LED's on the USB Interface show the communication status
- Simple installation of configuration software and drivers for the USB Interface
- User Instructions and Installation Guide included (on USB memory stick)
- Free download of configuration software, Consoft, and USB Interface software from our website

Specifications:

Input (PC to USB Interface)	USB cable
Output (USB Interface to transmitter)	Changeable transmitter cables
Power Supply	From USB port
Ambient temperature	
Operation	0 to 50 °C / 32 to 122 °F
Storage	-20 to 70 °C / -4 to 140 °F
Humidity	0 to 90 % RH
Galvanic isolation	1500 VAC
USB compliance	USB v.1.1 and USB v.2.0
System requirements	
Windows	2000 (SP3), XP (SP2+), Vista, Windows 7
Display resolution	Min. 800 x 600
Hard drive space	50 MB

Connection cables



PC to USB Interface

Part No:
70KAB49817



USB Interface to
IPAQ C201
MinIPAQ-HLP/-L
IPAQ C520/C520X
IPAQ R520/R520X

Part No:
70KAB49717



USB Interface to
IPAQ-Hplus/-Lplus
IPAQ-21L/-22LX
ProfIPAQ-H/-HX/-L

Part No:
70KAB49717

USB Interface to
IPAQ-L/LX
IPAQ-4L

Part No:
70KAB49719



USB Interface to
IPAQ-H/-HX

Part No:
70KAB49726

USB Interface



Part No:
70USBI0001

mm/inch

Ordering information

ICON Complete Configuration Kit	70CFGUS001
Separate parts	See above